

COIN VALIDATOR

RM5 WAKE UP

THE OPTIMAL AND EASIEST SOLUTION FOR THE COIN OPERATED BATTERY MACHINES

When a low consumption electronic validator is required it is possible to use a special version with wake up device installed.

This validator is normally in a "rest" position with consumption lower than 90 micro - Amperes.

As soon as a coin is inserted the validator goes in normal function for an established time, then back in "rest" position.

The jumper delivered with the electronic validator must be used only during reprogramming phase.

This jumper prevents the validator going into low consumption status allowing the programming or adjustment.

Put the jumper between the two pins of the wake up connector, as shown in the picture.

Remember to take it out otherwise the validator never goes in "rest" position and the battery will drain quickly.

